

ONE(1) YEAR LIMITED WARRANTY

PELONIS

• Please read all instructions before attempting to use this product.

- Please return the Warranty Registration card within fifteen (15) days from the date of purchasing this product.

Pelonis Appliance, INC., referred to hereafter as Pelonis Appliance, warrants as limited herein to the original purchaser of retail that each new FTW18-D2 Personal Clip-on Fan, shall be free of defects in material and workmanship for a period of one (1) year from the date of original purchase. This one (1) year warranty is limited to the fan motor, fan blades, and electric control circuit board.

In the event of malfunctions or failure of your FTW18-D2 Personal Clip-on Fan, simply deliver or send the product, postage prepaid along with **PROOF OF PURCHASE**, within the warranty period of one (1) year, to Pelonis Appliance. Pelonis Appliance reserves the right to inspect the claimed defective part or parts to determine if the defect or malfunction complaint is covered by this warranty. Pelonis Appliance shall, within sixty (60) days after receipt of the product, at its option, repair and/or replace the defective part or parts free of charge. This warranty shall only cover defects arising from normal usage.

Pelonis Appliance assumes no responsibility whatsoever if the FTW18-D2 Personal Clip-on Fan Fan should fail during the warranty period by reason of:

- Misuse, negligence, physical damage or accidents.
- Lack of maintenance (see instructions for proper maintenance).
- Repair by any unauthorized party during the warranty period.
- Damage caused by connection to an improper input voltage (see Operating Instructions for proper voltage information).

Pelonis Appliance makes no further warranties or representations, express or implied except those contained herein. No representative or dealer is authorized to assume any other liability regarding the FTW18-D2 Personal Clip-on Fan. The duration of the implied warranty granted under State law, including warranties of merchantability and fitness for particular purpose are limited in duration should the duration of the express warranty grant it hereunder. Pelonis Appliance shall in no event be liable for direct, indirect, special or consequential damages.

Some states do not allow limitations on how long an implied warranty lasts, and/or the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

Should your FTW18-D2 Personal Clip-on Fan fail to operate under the terms of this limited warranty, contact Pelonis Appliance at 866-876-4332 (M-F 9:00am to 5:00pm EST).


OWNER'S MANUAL

7"

Personal

Clip-on Fan

Model FTW18-D2



READ AND SAVE THESE INSTRUCTIONS

CAUTION:

Read Rules for Safe Operation and Instructions Carefully.

WARNING:

1. To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
2. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
3. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
4. Do not leave the fan running unattended.

RULES FOR SAFE OPERATION.

5. Never insert fingers, pencils, or any other object through the grill when fan is running.
6. Disconnect fan when moving from one location to another.
7. Disconnect fan when removing grills for cleaning.
8. Figs.1 through figs.3 illustrate the wrong way you clip to a structure and the wrong kind of structures to clip, to avoid as show to reduce the risk of damage.
9. DO NOT use fan in window. Rain may create electrical hazard.




Fig 1




Fig 2

OPERATING INSTRUCTIONS

10. place the clip onto a secure structure. The clip can accommodate a 3/4" to 1" thick structure.
11. Plug the power supply cord into a wall outlet.
12. Speed is controlled by the switch (low-off- hi), 1-0-2.
13. To start/stop the oscillation function, push down/pull the knob.
14. The airflow can be adjusted upward or downward by pushing the grills slightly to the desired up or down direction.

Fig 3

15. Be sure to unplug from the electrical supply source before cleaning.
16. Plastic parts should be cleaned with mild soap and damp cloth or sponge. Thoroughly to remove soap film with clean water.
17. Be sure not to make water or other liquid enter the inside of motor.

CLEANING

SPECIFICATIONS

Model No.:FTW18-D2
Voltage: 120v, 60Hz

**NOTE: PROOF OF PURCHASE IS REQUIRED FOR
ALL WARRANTY CLAIMS**